

1. 君正平台+6152/6256/6158 (sdio wifi) 常遇到无法认到 sdio 问题。
请在驱动入口添加如下 api。如下图所示

```
13: #else
14: #include <config/printk.h>
15: #endif
16:
17:
18: extern int ssvdevice_init(void);
19: extern void ssvdevice_exit(void);
20:
21: extern int jzmmc_manual_detect(int index, int on);
22: static __init int init_mmc_detect(void)
23: {
24:     jzmmc_manual_detect(1,1);
25:     return 0;
26: }
27:
28: static __exit int exit_mmc_detect(void)
29: {
30:     jzmmc_manual_detect(1,0);
31:     return 0;
32: }
33:
34: int initWlan(void)
35: {
36:     int ret=0;
37:     init_mmc_detect();
38:     printk(KERN_INFO "wlan.c initWlan\n");
39:     ret = ssvdevice_init();
40:     return ret;
41: }
42:
43: void exitWlan(void)
44: {
45:     exit_mmc_detect();
46:     ssvdevice_exit();
47:     return;
48: }
```